





Installation Instructions for AV/VC One

SINGLE SCREEN AND DUAL SCREEN CONFIGURATIONS













OVERVIEW


- AV/VC One System Overview
- Important Precautions
- Internal Equipment Space

MAIN INSTALLATION STEPS


- Main Structural Elements
- Assemble Column to Base
- Install Front Panel / Front Box
- Install Screen Support Brackets
- Install Screen Mount and Screen
- Install Additional Accessories
- 6 Cable Management
- Install Back Panel
- Optional Security Clips























⚠ IMPORTANT

- Maximum screen size to be mounted:
- Single screen installation: 80" max size. 60kg (132lbs) max weight.
- Dual screen installation: 65" max size. 60kg (132lbs) max weight.
- It is recommended that screens are removed before moving the AV/VC One unit.

- Do not install screens/displays heavier than 60kg/132lb. Total weight of installed equipment must not exceed 120kg/264lb, symmetrically distributed.
- Use with products heavier than the maximum weights indicated may result in instability causing possible injury.
- Correct installation is essential to safe and reliable operation of the AV/VC One product and falls outside the scope of responsibility of Colebrook Bosson Saunders. Please follow assembly instructions carefully.
- Do not use this product for any purpose other than that for which it was designed.
- Ensure that floor or wall surface is strong enough to support the weight of the fully-loaded AV/VC One and that the floor surface is flat and level.
- Do not install AV/VC One outdoors or in environments where it will be directly exposed to moisture or high winds.
- Follow the manufacturer's guidance for mounting of screens, displays and other equipment.
- Please take care to avoid trapping fingers when installing or adjusting the product.

⚠ ELECTRICAL SAFETY


- Safe installation of electrical equipment is the responsibility of the installer.
- Colebrook Bosson Saunders recommends that only double-insulated electrical equipment and cables are installed in AV/VC One unit.


- Ensure all screws and fixings are fully tightened and occasionally re-tighten if necessary.
- Clean with a dampcloth. DO NOT use solvents.

As part of Colebrook Bosson Saunders ongoing product improvement programme, the design of products may change without prior notice and details may vary from those illustrated.




INSTALLATION OF AV/VC ONE REQUIRES THE FOLLOWING MAIN STRUCTURAL ELEMENTS:









1 REMOVE BACK PANEL FROM COLUMN






INSTALL COLUMN TO BASE


1.3 FIX COLUMN TO BASE











.1 THE REQUIRED FRONT PANEL / FRONT BOX OPTION SHOULD BE INSTALLED AT THIS STAGE





















Choose fixing position to suit preferred mounting height of screen





3.2 INSTALL BRACKET

▲ IMPORTANT NOTE Ensure hooks are fully engaged













REPEAT FOR 2ND BRACKET















IMPORTANT

SINGLE SCREEN INSTALLATION

80" MAX SIZE

DUAL SCREEN INSTALLATION

65" MAX SIZE 60KG (132LBS) MAX WEIGHT







IF YOUR INSTALLATION REQUIRES ANY OF THE AV/VC ONE ACCESSORIES PLEASE INSTALL THEM AT THIS STAGE

AVS/021/FMI AV/VC One - Shelf Kit AVS/021/FMI AV/VC One - Powerstrip Mount Obtails to be cardinated SEE INSTALLATION INSTRUCTIONS SUPPLIED MYITH EACH ACCESSORY




6.1 INSTALL CABLE MANAGEMENT WITHIN COLUMN






.2 CABLE ENTRY / EXIT INTO UNIT




7.1 FIT BACK PANEL




7.2 CLOSE BACK PANEL

7.3 LOCK BACK PANEL




[OPTIONAL] VFINE ADJUSTMENT OF LOCK PLATE






SECURITY CLIPS PERMIT SECURE FIXING OF FRONT PANEL AND SCREEN SUPPORT BRACKETS


REMOVE SIDE COVER FIXING SCREW





LIFT AWAY COVER





INSERT CLIPS




















INSTALLATION IS NOW COMPLETE



PLEASE CONS

PLEASE CONSIDER LEAVING THESE INSTRUCTIONS WITH THE UNIT IF FURTHER INSTALLATION MAY BE REQUIRED BY OTHERS