


RODNEY DESK CLAMP INSTRUCTIONS

SUN-001-INST-F-FEB2013

MOUNT ARMS ON TO DESK CLAMP









IMPORTANT Once assembled joints can not be separated

MOUNT TO DESK



MOUNT MONITOR HEAD


Use screws supplied



Adjustment knob point downwards


IMPORTANT

It is the responsibility of the installer to ensure all mounting screws are properly engaged with a minimum of 4 x 360° turns into the display. Under or over insertion may cause damage to the equipment or injury to personnel







LOADING MONITOR AND SECURING TOP CAP



CABLE MANAGEMENT




MONITOR ADJUSTMENT




IF MONITOR DOES NOT BALANCE

To adjust friction



COMPONENT LIST



WARNING

• Ensure desk / work surface / wall / partition is suitable to take the weight of the arm/s and monitors.

• Do not use this product for any purpose other than that for which it was designed.

• Supported weight must not exceed 8.5kg (18.7lb) per arm.

• Hold the monitor tightly when making adjustments.

• Care should be taken to avoid trapping fingers.

• Do not dismantle or remodel the arms.

• Do not attach the monitor before assembling the arm.

• Some monitors have recesses and may require spacers or a 75mm VESA plate.

MAINTENANCE AND INSPECTION

• The use of power tools, lever bars or excessive force during the installation, or re-configuration of the product will invalidate your guarantee.
• Failure to observe the recommendations in the use, and configuration of these products may affect your guarantee.

PATENT AND DESIGN REGISTRATION
This product is protected by one or more GB and International patents pending:
GB2438581; GB0705479.4; GB0725381.8 and WO07/137905
and by Registered Community Design No. 000694732-0001-0005.
Other foreign design registrations pending



www.colebrookbossons aunders.com

colebrook bosson saunders

FOLD FOLD FOLD